


**Put golfers on solid footing.**

Even today's short plastic spikes collect debris and require cleaning. Our spike brushes ensure clean spikes and good footing at the tee, and less debris tracked in at the clubhouse. Attach them to every ball washer for player convenience and station a freestanding spike brush outside every clubhouse entrance.

**SPIKE BRUSHES**

- Crimped nylon bristles are dense to prevent matting, yet soft enough for both spikeless and plastic spiked shoes.
- Base is made of black anodized cast aluminum, so there's no paint to chip.



**FLOOR MOUNT COMBINATION SPIKE AND SHOE CLEANER**

549-11



**SINGLE PIPE MOUNT SPIKE BRUSH**

Mounts easily to ball washer pipe.

552-11



**DOUBLE PIPE MOUNT SPIKE BRUSH**

Mounts easily to ball washer pipe.

553-11



**SPIKE BRUSH PARTS BASE BRUSH**

554-11 Fits all models



**SIDE BRUSH**

548 Fits 549-11, 512-11 & 513-11 models



**PIPE MOUNT BACK CLAMP**

552-3 With hardware