


LHD - 2400

Parts List




ENGINE AND CARBURETOR ASSEMBLY PARTS LIST

ENGINE, LHD - 2400 HEDGE CLIPPER — PARTS LIST

Ref. LESCO No.	No.	Description	No. Used	Ref. LESCO No.	No.	Description	No. Used	Ref. LESCO No.	No.	Description	No. Used	
	1	451123	Crankshaft	1	43	450992	Baffle Plate	1	78	450997	Rubber	2
	2	450979	Piston Assembly (Includes 1 Ref. 3) 1	44	451099	Gasket	1	79	450956	Rubber	1	
<i>451255</i>	3	450794	Ring, Piston	45	See Ref.81	- Gasket, Insulator	1	80	451139	Hose	1	
	4	450973	Pin, Piston	46	450993	Bolt, M5x56	2	81	450998	Gasket Kit (Includes 1 ea. Ref. 37, 45 and 52)	1	
	5	450794	Clip, Piston Pin	47	450995	Insulator	1					
	6	450976	Bearing, Needle	48	450941	Adjuster	1					
	7	450980	Crankcase Assembly (Includes 1 ea. Ref. 8, 9 and 2 ea. Ref. 10)	49	450053	Bolt, M5x12	1	<i>82</i>	<i>450902</i>	<i>SPARK ARRESTER</i>		
	8	450009	Bearing, Ball, 6201	50	027090	Nut	1	<i>83</i>	<i>451256</i>	<i>MUFFLER GASKET</i>		
	9	450010	Seal, Oil	51	029349	Washer	2					
	10	450012	Pin, Dowel	52	See Ref.81	- Gasket	1					
	11	450974	Crankcase Assembly (Includes 1 ea. Ref. 8 and 9)	53	450938	Carburetor Assembly (Includes 1 ea. Ref. 54, 55, 56, 57, 58 and 59)	1					
	12	450062	Bolt, M5x25	54	450943	Valve, Float	1					
	14	451125	Clutch Assembly	55	450068	Gasket	1					
	15	451126	Adapter	56	450069	Diaphragm, Metering	1					
<i>2</i>	19	450975	Coil Assembly, Ignition	57	450070	Diaphragm, Pump	1					
	20	450889	Bolt, M4x20	58	450945	Gasket	1					
	21	450044	Spring	59	450072	Rubber	1					
	22	450045	Cap, Plug	60	450944	Case, Air Silencer	1					
	23	058125	Spark Plug	61	450990	Nut	2					
	24	451127	Flywheel, Magneto	62	450911	Element "B", Air Filter	1					
	25	450025	Nut	63	450903	Element "A", Air Filter	1					
	27	451128	Housing, Assembly, Blower	64	450994	Cap, Case	1					
	28	451129	Ratchet	65	451136	Wire Complete, Throttle	1					
	29	451130	Rope, Starter	66	451137	Tank, Fuel	1					
	30	450833	Knob, Starter	67	450084	Cap Assembly, Fuel Tank (Includes 1 Ref. 68)	1					
	31	450836	Name Plate	68	450085	Gasket	1					
	32	451131	Caution Plate	69	450081	Filter, Fuel	1					
	33	450022	Bolt, M5x16	70	450082	Clip	1					
	36	450985	Cylinder	71	450083	Hose	1					
	37	See Ref.81	- Gasket, Muffler	72	451138	Rubber	1					
	38	450991	Muffler	73	450090	Hose	2					
	39	450055	Arrester	74	450093	Rubber	1					
	40	450986	Baffle Plate, Outer	75	450091	Valve, Reversing	1					
	41	450075	Bolt, M5x48	76	450767	Clip	1					
	42	451132	Cowling, Cylinder	77	450768	Connector	1					

CLIPPER, LTD - Z400 HEDGE CLIPPER

3



CLIPPER, LHD - 2400 HEDGE CLIPPER — PARTS LIST

Ref. LESCO		Description	No. Used	Ref. LESCO		No. Used	
No.	No.			No.	No.		
1	451144	Handle	1	41	451180	Wire Holder	1
2	451145	Plate	1	42	451181	Piece, Set	1
3	451146	Drum, Clutch	1	43	451182	Switch, Stop	1
4	451147	Case, Gear	1	44	451183	Lever	1
5	450990	Nut	2	45	451184	Snap Ring	1
6	450110	Bolt, M6x14	2	46	451185	Handle	1
8	450098	Bearing, Ball, 6001	1	47	451186	Screw, M4x16	5
9	451151	Bearing, Ball, 608Z	3	48	451187	Screw, M4x30	1
10	451152	Nut	2	49	451188	Handle	1
11	451153	Gear, Pinion	1	50	451189	Nut	6
12	451154	Gear, Crank	1	51	450119	Wrench, Spanner Box 19	1
13	451155	Rod	2	52	451191	Manual, Operator's	1
14	451156	Snap Ring, S-26	1				
15	451157	Bolt, M6x35	2				
17	451158	Screw, M3x5	2				
18	451159	Plate	1				
4	19	451160	Felt	1			
20	451161	Case, Gear	1				
21	450022	Bolt, M5x16	5				
22	450047	Bolt, M5x20	2				
23	451164	Nut	4				
26	451165	Screw, M5x20	2				
27	451166	Washer	4				
28	451167	Screw	3				
29	451168	Plate	1				
30	451169	Blade	1				
31	451170	Blade	1				
32	027274	Nut	1				
33	451172	Bolt, M6x45	1				
34	451173	Bolt, M6x50	1				
35	451174	Screw	1				
36	451175	Cover, Balde	1				
37	451176	Handle	1				
38	451177	Plate	1				
39	451178	Lever	1				
40	451179	Screw, M4x10	1				

DECAL INFORMATION

WARNING

LOCATE THE SAFETY DECALS ON YOUR CLIPPER. MAKE SURE THE DECALS ARE LEGIBLE AND THAT YOU UNDERSTAND AND FOLLOW THE INSTRUCTIONS ON THEM.

GENERAL WARNING DECAL

LHD 2400

CAUTION

Read and understand all safety messages in operator's manual before using this machine.
Improper use of this product can cause bodily injury.
Keep shields in place at all times. Always wear eye protection when operating this machine. Permit only the operator in the area of operation.

GENERAL WARNING DECAL

