


LST - 3500

Trimmer

Parts List

ENGINE, LST - 3500 TRIMMER



ENGINE, LST - 3500 TRIMMER — PARTS LIST


Ref. LESCO No.	No.	Description	No. Used	Ref. LESCO No.	No.	Description	No. Used	Ref. LESCO No.	No.	Description	No. Used
1	450001	Crankshaft	1	34	450034	Housing, Blower	1	72	450072	Rubber	1
2	450002	Key	1	35	450035	Grommet	1	73	See Ref. 95	- Gasket, Air Silencer	1
3	450003	Piston Assembly (Includes 2 Ref. 4)	1	36	450036	Rubber	1	74	450074	Case, Air Silencer	1
4	450004	Ring, Piston	2	37	450037	Pipe	1	75	450075	Bolt, M5x48	2
5	450005	Pin, Piston	1	38	450038	Snap Ring, R-47	1	76	450076	Element "A", Air Filter	1
6	450006	Clip, Piston Pin	2	39	450039	Bolt, M4x12	2	77	450077	Cap, Case (Includes 1 ea. Ref. 78 and 79)	1
7	450007	Bearing, Needle	1	40	450040	Bolt, M6x20	1	78	450078	Bolt	1
8	450008	Crankcase Assembly (Includes 1 ea. Ref. 9 and 10)	1	41	450041	Wire Complete, Throttle	1	79	450079	Snap Ring, E-5	1
9	450009	Bearing, Ball	2	43	450043	Coil Assembly, Ignition	1	80	450080	Tank, Fuel	1
10	450010	Seal, Oil	2	44	450044	Spring	1	81	450081	Filter, Fuel	1
11	450011	Crankcase Assembly (Includes 1 ea. Ref. 9 and 10)	1	45	450045	Cap, Plug	1	82	450082	Clip	1
12	450012	Pin, Dowel	4	46	058125	Spark Plug	1	83	450083	Hose	1
13	450013	Shim, 0.1mm	As Req'd.	47	450047	Bolt, M5x20	2	84	450084	Cap Assembly, Fuel Tank (Includes 1 Ref. 85)	1
14	450014	Bolt, M5x30	4	48	450048	Cylinder	1	85	450085	Gasket	1
15	450015	Pulley Assembly, Starter (Includes 1 Ref. 16)	1	49	450049	Gasket, Cylinder	1	86	450086	Stay, Stand	1
16	450016	Ratchet	1	50	See Ref. 95	- Gasket, Muffler	1	87	450087	Cowling, Cylinder	1
17	450017	Nut	1	51	450051	Muffler	1	88	450088	Name Plate	1
18	450018	Recoil Assembly (Includes 1 ea. Ref. 19, 20 and 21)	1	52	450052	Bolt, M5x58	2	89	450089	Rubber	1
19	450019	Spring, Sprial	1	53	450053	Bolt, M5x12	4	90	450090	Hose	1
20	450020	Knob, Starter	1	54	See Ref. 95	- Gasket, Baffle Plate	1	91	450091	Valve, Reversing	1
21	450021	Rope, Starter	1	55	450055	Arrester	1	92	450092	Hose	1
22	450022	Bolt, M5x16	14	56	450056	Baffle Plate, Outer	1	93	450093	Rubber	1
23	450023	Name Plate	1	57	450057	Bolt, M4x6	4	94	450094	Bolt, M5x14	4
24	450024	Flywheel, Magneto	1	58	450058	Baffle Plate	1	95	450763	Gasket Kit (Includes 1 ea. Ref. 50, 54, 59, 65 and 73.)	1
25	450025	Nut	1	59	See Ref. 95	- Gasket, Insulator	1	96	450767	Clip	1
26	450026	Clutch Assembly	1	60	450060	Insulator	1	97	450768	Connector	1
27	450027	Spacer	2	61	029349	Washer	2	98	450901	Wire Holder	1
28	450028	Spacer	2	62	450062	Bolt, M5x25	2				
29	450029	Bolt	2	63	450063	Adjuster	1				
30	450030	Drum, Clutch	1	64	450064	Element "B", Air Filter	1				
31	450031	Snap Ring, R-35	1	65	See Ref. 95	- Gasket	1				
32	450032	Bearing, Ball	1	66	450066	Carburetor Assembly (Includes 1 ea. Ref. 67, 68, 69, 70, 71 and 72)	1				
33	036601	Snap Ring, S-15	1	67	450067	Valve, Float	1				
				68	450068	Gasket	1				
				69	450069	Diaphragm, Metering	1				
				70	450070	Diaphragm, Pump	1				
				71	450071	Gasket	1				

99 451257 Rock

SHAWT Block
PT# 451197

SHAFT, LST - 3500 TRIMMER

3



SHAFT, LST - 3500 TRIMMER — PARTS LIST

Ref. LESCO		Description	No. Used	Ref. LESCO		Description	No. Used
No.	No.			No.	No.		
1	450106	Shaft, Drive	1	21	450098	Bearing, Ball	1
2	450108	Pipe, Complete (Includes 6 Ref. 3)	1	22	450118	Snap Ring, R-28	1
3	450105	Metal	6	23	450099	Holder	1
4	450109	Hanger	1	24	450121	Cover	1
5	450110	Bolt, M6x14	1	25	450125	Holder	1
6	450095	Grip	1	26	450100	Cover, Bolt	1
7	450111	Lever Assembly, Throttle	1	27	450120	Nut, LH M10x1.25	1
8	450104	Deflector, Steel	1	28	450126	Handle, Loop (Includes 2 ea. Ref. 29)	1
9	450113	Plate	1	29	450033	Bolt, M6x12	2
10	450047	Bolt, M5x20	6	30	450123	Harness, Shoulder	1
11	450103	Deflector Assembly, Plastic (Includes 1 ea. Ref. 12 and 13)	1	31	450119	Wrench, Spanner Box 13x19	1
12	450114	Cutter	1	32	450102	Wrench, Key, 4mm	1
13	450022	Bolt, M5x16	1	33	450129	Bag, Tool	1
14	450115	Case Assembly, Gear (Includes 1 ea. Ref. 15, 16, 17, 18, 19, 21 and 22 and 2 ea. Ref. 10 and 20) ..	1	34	036506	Manual, Operator's	1
15	450096	Bolt, M6x8	1	35	450130	Goggles	1
16	450117	Bolt, M5x10	1	36	450101	Blade, 4 Tooth	1
17	450122	Snap Ring, R-26	1	37	450112	Blade, 8 Tooth	1
18	036571	Snap Ring, S-10	1	38	450738	Blade, Circular	1
19	450124	Bearing, Ball	1	39	022411	Trimmer Head	1
20	450116	Bearing, Ball	2				



LIMITED WARRANTY FOR HAND HELD POWER EQUIPMENT

LESCO, Inc.'s limited warranty promises to you, the original retail purchaser, that the unit of LESCO hand held power equipment you purchased (the "Product") will be free from defects in material and workmanship for a period of one (1) year from the date of retail purchase (the "Warranty period"). LESCO agrees to repair or replace, at LESCO's option, any defective Product free of charge during the Warranty Period. Upon completion of your purchase, the Serial Number of the Product will be registered with LESCO, Inc. This will initiate and validate your limited warranty. Please keep your purchase receipt and present it to an authorized LESCO servicing facility for warranty service. Parts replaced or repaired under this limited warranty are warranted only to the end of the Warranty Period. All defective parts replaced under this Limited Warranty become the property of LESCO, Inc. For warranty service, you must, at your own expense, deliver the Product to, and pick it up from, an authorized LESCO servicing facility. To locate your nearest authorized LESCO servicing facility, call LESCO, Inc. toll free at 1-800-321-5325.

This limited warranty is given by LESCO to the original retail purchaser only, and is not transferable to subsequent owners. This warranty does not cover damage to the Product resulting from any cause other than defects in material or workmanship. This warranty specifically does not cover damage caused by:

1. Lack of lubrication or engine failure due to the use of oils other than LESCO-approved oils.
2. The use of gasohol containing methyl (wood) alcohol or gasoline containing less than 89 octane. Only use gasoline which contains 89 octane or higher or gasohol which contains a maximum 10% ethyl (grain) alcohol or 15% MTBE (methyl tertiary-butyl ether). (The prescribed mixing ratio of gasoline to oil is listed on the LESCO oil label.)
3. Defects, malfunctions or failures resulting from abuse, misuse, modifications, alterations, improper servicing or maintenance, improper storage, use of unauthorized attachments, including, without limitation, failure to provide or perform required maintenance services as described in the Operator's Manual.
4. Tampering with engine speed governors or running engines above specified and recommended engine speeds.
5. Dirt, salt water corrosion, rust, varnish and moisture.
6. Operation of the Product with improperly serviced, damaged or removed air filter.
7. Failure to follow the set-up, pre-delivery service and adjustments outlined in the Operator's Manual.
8. Parts which are not warranted. (This limited warranty does not cover parts which are normal wear or maintenance items, including, without limitation, spark plugs, filters, lubricants, engine tune-up parts, spark arrestor screen, cutting line and starter cords.)
9. Engine damage caused by the use of ether or any starting fluids.
10. Damage caused by the pressure of steam cleaning the Product.
11. Repairs or alterations made to the Product by an unauthorized party.

THIS LIMITED WARRANTY IS IN PLACE OF ALL OTHER EXPRESS AND IMPLIED WARRANTIES. ANY IMPLIED WARRANTY, SUCH AS FITNESS FOR A PARTICULAR PURPOSE OR MERCHANTABILITY, IS EXCLUDED. REPAIR OR REPLACEMENT UNDER THIS LIMITED WARRANTY IS EXPRESSLY AGREED TO BE THE EXCLUSIVE REMEDY. LESCO, INC. WILL NOT BE LIABLE FOR ANY SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES.

SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER LEGAL RIGHTS WHICH VARY FROM STATE TO STATE.

HOW TO ORDER PARTS

Contact your LESCO Salesperson, OR phone us (use the numbers below), OR write us (use the address below). We will need the following information:

1. Your account number if available.
2. Your name and address and the address where you want the parts to be shipped.
3. The Model/Serial No. of the equipment.
4. The LESCO Part No. and the quantity desired. (Please do not use reference numbers.)

NOTE: Inspect all shipments on receipt for damage or missing parts. File a claim with the carrier before accepting a damaged shipment.

We reserve the right to change designs, specifications and equipment at any time without notice and without incurring any obligations.

LESCO, Inc., 20005 Lake Road, Rocky River, Ohio 44116-1545
Toll Free (800) 321-5325 • In the Cleveland Area (216) 333-9250

