


LST - 2300

Trimmer

Parts List

ENGINE, LST - 2300 TRIMMER




ENGINE, LST - 2300 TRIMMER — PARTS LIST

Ref. LESCO No.	No.	Description	No. Used	Ref. LESCO No.	No.	Description	No. Used	Ref. LESCO No.	No.	Description	No. Used
1	450773	Crankshaft	1	34	450864	Housing, Blower	1	72	450084	Cap Assembly, Fuel Tank (Includes 1 Ref. 73)	1
2	450002	Key	1	35	450022	Bolt, M5x16	8	73	450085	Gasket	1
3	450782	Piston Assembly (Includes 2 Ref. 4)	1	36	450869	Drum, Clutch	1	74	450081	Filter, Fuel	1
4	450791	Ring, Piston	2	37	036571	Snap Ring, S-10	1	75	450082	Clip	1
5	450793	Pin, Piston	1	38	450035	Grommet	1	76	450948	Hose	1
6	450794	Clip, Piston Pin	2	40	450014	Bolt, M5x30	1	77	450951	Rubber	1
7	450796	Bearing, Needle	1	41	450871	Nut	1	78	450090	Hose	1
8	450803	Crankcase Assembly (Includes 1 ea. Ref. 9, 10 and 2 ea. Ref. 11)	1	42	450874	Cylinder	1	79	450093	Rubber	1
9	450116	Bearing, Ball	1	43	See Ref. 86	Gasket, Muffler	1	80	450954	Hose	1
10	450804	Seal, Oil	2	44	450872	Muffler	1	81	450091	Valve, Reversing	1
11	450012	Pin, Dowel	2	45	450055	Arrester	1	82	450949 450767	Clip	1
12	450808	Crankcase Assembly (Includes 1 ea. Ref. 10 and 19)	1	46	450876	Baffle Plate, Outer	1	83	450955 450768	Connector	1
13	450813	Shim, 0.1mm	As Req'd.	47	450075	Bolt, M5x48	4	84	450953	Rubber	2
14	450809	Shim, 0.2mm	As Req'd.	48	450936	Cowling, Cylinder	1	85	450956	Rubber	1
14	450815	Pulley Assembly, Starter (Includes 1 Ref. 15)	1	49	450940	Baffle Plate	1	86	450952	Gasket Kit (Includes 1 ea. Ref. 43, 51 and 58.)	1
15	450823	Ratchet	1	50	450942	Name Plate	1	87.	451253	ROCK	
16	450816	Recoil Assembly (Includes 1 ea. Ref. 17 and 18)	1	51	See Ref. 86	Gasket, Insulator	1	88.	451254	SPRING	
17	450827	Rope, Starter	1	52	450937	Insulator	1				
18	450833	Knob, Starter	1	53	450941	Adjuster	1				
19	450828	Bearing, Ball	1	54	450053	Bolt, M5x12	4				
20	450836	Name Plate	1	55	027090	Nut	1				
21	450829	Coil Assembly, Ignition	1	56	029349	Washer	2				
22	450831	Insulator	1	57	450062	Bolt, M5x25	2				
23	050889	Bolt, M4x20	2	58	See Ref. 86	Gasket	1				
24	450044	Spring	1	59	450938	Carburetor Assembly (Includes 1 ea. Ref. 60, 61, 62, 63, 64 and 65)	1				
25	450045	Cap, Plug	1	60	450943	Valve, Float	1				
26	058125	Spark Plug	1	61	450946	Gasket	1				
27	450844	Flywheel, Magneto	1	62	450950	Diaphragm, Metering	1				
28	450847	Clutch Assembly	1	63	450939	Diaphragm, Pump	1				
29	450854	Spacer	2	64	450945	Gasket	1				
30	450857	Spacer	2	65	450072	Rubber	1				
31	450860	Bolt	2	66	450944	Case, Air Silencer	1				
32	450862	Nut	1	67	450964	Element "B", Air Filter	1				
33	450047	Bolt, M5x20	5	68	450976	Element "A", Air Filter	1				
				69	450977	Cap, Case	1				
				70	450041	Wire Complete, Throttle	1				
				71	450947	Tank, Fuel	1				

START BLOCK
 P/N 451195

450911
 450903
 450910

SHAFT, LST - 2300 TRIMMER



SHAFT, LST - 2300 TRIMMER — PARTS LIST

Ref. LESCO			No.	Ref. LESCO			No.
No.	No.	Description	Used	No.	No.	Description	Used
1	450971	Shaft, Drive	1	22	450118	Snap Ring, R-28	1
2	450957	Pipe, Complete (Includes 6 Ref. 3)	1	23	450099	Holder	1
3	450964	Metal	6	24	450121	Cover	1
4	450967	Hanger	1	25	450125	Holder	1
5	450110	Bolt, M6x14	1	26	450100	Cover, Bolt	1
6	450958	Grip	1	27	450120	Nut, LH M10x1.25	1
7	450961	Lever Assembly, Throttle	1	28	450963	Handle, Loop (Includes 2 ea. Ref. 29)	1
10	450047	Bolt, M5x20	6	29	450033	Bolt, M6x12	2
11	450103	Deflector Assembly, Plastic (Includes 1 ea. Ref. 12 and 13)	1	30	450119	Wrench, Spanner Box 13x19	1
12	450114	Cutter	1	31	450102	Wrench, Key, 4mm	1
13	450022	Bolt, M5x16	1	32	450129	Bag, Tool	1
14	450959	Case Assembly, Gear (Includes 1 ea. Ref. 15, 16, 17, 18, 19, 21 and 22 and 2 ea. Ref. 10 and 20) ..	1	33	036506	Manual, Operator's	1
15	450096	Bolt, M6x8	1	34	450130	Goggles	1
16	450117	Bolt, M5x10	1	35	450061	Blade, 4 Tooth	1
17	450962	Snap Ring, R-24	1	36	450107	Blade, 8 Tooth	1
18	450965	Snap Ring, S-9	1	37	450730	Blade, Circular	1
19	450960	Bearing, Ball	1	38	022411	Trimmer Head	1
20	450966	Bearing, Ball	2	39	450969	Rubber	1
21	450098	Bearing, Ball	1	40	450968	Bolt, M5x8	1
				41	450970	Collar	1
				42	029349	Washer, 5mm	1



LIMITED WARRANTY FOR HAND HELD POWER EQUIPMENT

LESCO, Inc.'s limited warranty promises to you, the original retail purchaser, that the unit of LESCO hand held power equipment you purchased (the "Product") will be free from defects in material and workmanship for a period of one (1) year from the date of retail purchase (the "Warranty period"). LESCO agrees to repair or replace, at LESCO's option, any defective Product free of charge during the Warranty Period. Upon completion of your purchase, the Serial Number of the Product will be registered with LESCO, Inc. This will initiate and validate your limited warranty. Please keep your purchase receipt and present it to an authorized LESCO servicing facility for warranty service. Parts replaced or repaired under this limited warranty are warranted only to the end of the Warranty Period. All defective parts replaced under this Limited Warranty become the property of LESCO, Inc. For warranty service, you must, at your own expense, deliver the Product to, and pick it up from, an authorized LESCO servicing facility. To locate your nearest authorized LESCO servicing facility, call LESCO, Inc. toll free at 1-800-321-5325.

This limited warranty is given by LESCO to the original retail purchaser only, and is not transferable to subsequent owners. This warranty does not cover damage to the Product resulting from any cause other than defects in material or workmanship. This warranty specifically does not cover damage caused by:

1. Lack of lubrication or engine failure due to the use of oils other than LESCO-approved oils
2. The use of gasohol containing methyl (wood) alcohol or gasoline containing less than 89 octane. Only use gasoline which contains 89 octane or higher or gasohol which contains a maximum 10% ethyl (grain) alcohol or 15% MTBE (methyl tertiary-butyl ether). (The prescribed mixing ratio of gasoline to oil is listed on the LESCO oil label.)
3. Defects, malfunctions or failures resulting from abuse, misuse, modifications, alterations, improper servicing or maintenance, improper storage, use of unauthorized attachments, including, without limitation, failure to provide or perform required maintenance services as described in the Operator's Manual
4. Tampering with engine speed governors or running engines above specified and recommended engine speeds
5. Dirt, salt water corrosion, rust, varnish and moisture.
6. Operation of the Product with improperly serviced, damaged or removed air filter.
7. Failure to follow the set-up, pre-delivery service and adjustments outlined in the Operator's Manual
8. Parts which are not warranted. (This limited warranty does not cover parts which are normal wear or maintenance items, including, without limitation, spark plugs, filters, lubricants, engine tune-up parts, spark arrestor screen, cutting line and starter cords.)
9. Engine damage caused by the use of ether or any starting fluids
10. Damage caused by the pressure of steam cleaning the Product.
11. Repairs or alterations made to the Product by an unauthorized party.

THIS LIMITED WARRANTY IS IN PLACE OF ALL OTHER EXPRESS AND IMPLIED WARRANTIES. ANY IMPLIED WARRANTY, SUCH AS FITNESS FOR A PARTICULAR PURPOSE OR MERCHANTABILITY, IS EXCLUDED. REPAIR OR REPLACEMENT UNDER THIS LIMITED WARRANTY IS EXPRESSLY AGREED TO BE THE EXCLUSIVE REMEDY. LESCO, INC. WILL NOT BE LIABLE FOR ANY SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES.

SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER LEGAL RIGHTS WHICH VARY FROM STATE TO STATE.

HOW TO ORDER PARTS

Contact your LESCO Salesperson, OR phone us (use the numbers below), OR write us (use the address below). We will need the following information:

1. Your account number if available.
2. Your name and address and the address where you want the parts to be shipped.
3. The Model/Serial No. of the equipment.
4. The LESCO Part No. and the quantity desired. (Please do not use reference numbers.)

NOTE: Inspect all shipments on receipt for damage or missing parts. File a claim with the carrier before accepting a damaged shipment.

We reserve the right to change designs, specifications and equipment at any time without notice and without incurring any obligations.

LESCO, Inc., 20005 Lake Road, Rocky River, Ohio 44116-1545
Toll Free (800) 321-5325 • In the Cleveland Area (216) 333-9250

