


HEDGE CLIPPER

MODEL LHD-1700

SERIAL NUMBER 004338 & UP


LESCO™

LHD1700




LESCO No.	Description	No. Pcs.	LESCO No.	Description	No. Pcs.
1	060114 OILSEAL	2	13	054596 CRANKCASE SET INCLUDES ITEM 14	1
2	093607 SPACER, PISTON PIN	2	14	094428 PIN, DOWEL	2
3	075288 BEARING, NEEDLE	1	15	----- GASKET, CRANKCASE USE KIT 091921	1
4	066718 PISTON KIT INCLUDES ITEMS 5 - 7	1	16	027812 BEARING, BALL 6201	2
5	048344 CIRCLIP, PISTON PIN	2	17	051479 CRANKSHAFT INCLUDES ITEM 3	1
6	029168 PIN, PISTON	1	18	051481 SCREW 5X28	3
7	023943 RING, PISTON	1	ENGINE REPOWER		
8	086794 COVER, CYLINDER	1	069556	SHORT BLOCK INCLUDES FACTORY ASSEMBLED CYLINDER, CRANKCASE, PISTON CRANKSHAFT, BEARINGS & SEALS	1
9	051342 SCREW 4X20	2			
10	080256 BOLT, H.S. 5X22	2			
11	032660 CYLINDER	1			
12	051465 GASKET, CYLINDER BASE USE KIT 091921	1			

LHD1700




LESCO No.	Description	No. Pcs.	LESCO No.	Description	No. Pcs.
1	NUT, WING 5	1	13	SCREW 5X20	2
2	COVER, AIR CLEANER	1	14	MUFFLER ASY INCLUDES ITEMS 7 - 11	1
3	LABEL, CHOKE	1	15	GASKET, MUFFLER	2
4	FILTER, AIR	1	16	COVER, MUFFLER	1
5	SCREW 5X64	2	17	MUFFLER	1
6	PLATE, PREVENT	1	18	SCREEN, MUFFLER	1
7	CASE, AIR CLEANER	1	19	GASKET, MUFFLER LID	1
8	CARBURETOR C1U-K27B	1	20	HOLDER, SCREEN	1
9	GASKET, INTAKE	1	21	SCREW 4X10	3
10	INSULATOR	1	22	BOLT, H.S. 5X50	2
11	NUT 5	2	23	WASHER 5	2
12	GASKET, INTAKE1				

LHD1700





LESCO No.	Description	No. Pcs.	LESCO No.	Description	No. Pcs.
1	SCREW 4X16	4	19	093116 FLYWHEEL	1
2	LABEL, LESCO	1	20	061129 PAWL ASY, STARTER INCLUDES ITEMS 21 - 24	1
3	LABEL, MODEL	1	21	038737 E-RING 4	1
4	STARTER ASY INCLUDES ITEMS 5 - 9, 25 - 27	1	22	033448 CATCHER, PAWL	1
5	COVER, FAN	1	23	088528 SPRING, RETURN	1
6	SPRING, REWIND	1	24	056406 PAWL, STARTER	1
7	DRUM, STARTER	1	25	038661 ROPE, STARTER USE BULK ROPE 050553 DIA. 3.0 MM (.12") X 890 MM (35.0")	1
8	WASHER	1	26	038471 GUIDE, ROPE	1
9	SCREW	1	27	052307 GRIP, STARTER	1
10	NUT 8 (3)	1	28	051382 SCREW 4X16	2
11	WASHER 8	1	29	070558 HOUSING, CLUTCH	1
12	BOLT 4X22	2	30	039638 CLUTCH ASY INCLUDES ITEMS 31 - 33	1
13	COIL, IGNITION	1	31	036093 HUB, CLUTCH	1
14	GROMMET	1	32	078782 SHOE, CLUTCHq2	1
15	PLUG, SPARK BPM-6A	1	33	077491 SRPING, CLUTCH	2
16	COIL, SPARK PLUG CAP	1	34	055981 PLATE, CLUTCH	1
17	CAP, SPARK PLUG	1	35	026553 WASHER, CLUTCH	1
18	GROMMET	1			




LESCO No.	Description	No. Pcs.
1 078701	HANDLE SET, REAR	1
2 044153	WASHER 5	4
3 040800	LOCKNUT 5	3
4 082042	WASHER	1
5 093714	HANDLE, FRONT	1
6 045845	WASHER 6	2
7 082143	NUT 6 (3)	2
8 037579	LEAD, GROUND	1
9 048194	LEAD, GROUND	1
10 043121	WIRE, THROTTLE	1
11 067484	SWITCH, IGNITION	1
12 052536	CONTROL, THROTTLE	1
13 057761	SCREW 5X50	2
14 058844	SCREW 4X16	5
15 051484	PIN, SPRING 5X25	1
16 097004	LOCKNUT, THROTTLE CONTROL	1
17 045370	SPRING, THROTTLE RETURN	1

LESCO No.	Description	No. Pcs.
1 051482	TANK, FUEL <i>038548</i>	1
2 072951	SCREW 5X16	2
3 060744	WASHER 5	2
4 041506	PIPE 3X5X195	1
5 033688	VENT ASY	1
6 034913	PIPE 3X5X70	1
7 093287	GROMMET	1
8 076965	CLIP	1
9 075165	STRAINER, FUEL	1
10 076047	CAP ASY, FUEL TANK INCLUDES ITEM 11	1
11 097180	GASKET, FUEL TANK CAP	1
12 052802	PIPE, RETURN	1





LESCO No.	Description	No. Pcs.	LESCO No.	Description	No. Pcs.
1	089834 CASE, GEAR	1	14	098315 ROD, CONNECTING	2
2	088464 SCREW	1	15	089095 GEAR, SPUR	1
3	059165 LOCKNUT 6	4	16	034180 WASHER	1
4	092036 BAR, FRAME	1	17	096237 HOLDER, FRAME	1
5	022664 SCREW 6X18	2	18	031741 SCREW 5X20	3
6	000250 CUTTER	2	19	054425 DRUM, CLUTCH	1
7	033527 BOLT, CUTTER	3	20	063348 CIRCLIP 35	1
8	048802 WASHER	4	21	072051 BEARING, BALL 6202	1
9	052815 BOLT, CUTTER	1	22	032357 BEARING, BALL 6202	1
10	028224 SCREW 4X10	6	23	054636 CIRCLIP 14	1
11	057819 COVER, GEARCASE	1	24	056086 WRENCH, W/SCREWDRIVER	1
12	079134 GASKET, GEAR HOUSING	1	25	057704 SPANNER 8X10	1
13	058450 FELT	1	26	023529 NUT, LOCK	1



LESCO No.	Description	No. Pcs.	LESCO No.	Description	No. Pcs.
025113 051500	CARBURETOR C1U-K27B	1	21	B STRAINER	1
1	063916 SCREW	2	22	AB DIAPHRAGM, FUEL PUMP	1
2	056122 BASE PRIMER	1	23	AB GASKET, FUEL PUMP	1
3	AB DIAPHRAGM	1	24	073780 COVER, PUMP	1
4	AB GASKET, DIAPHRAGM	1	25	096150 SCREW	2
5	B SCREW	1	26	074606 PUMP, PRIMER	1
6	B PIN	1	27	076192 RING	1
7	B LEVER, METERING CHAM	1	28	018999 SCREW	2
8	B SPRING, COIL	1	29	040391 SCREW, IDLE ADJUST	1
9	B VALVE, NEEDLE	1	30	037461 PIECE, FRICTION	1
10	035101 CLIP	1	31	051486 NOZZLE, CHECK VALVE	1
11	B PLUG, WELCH	1	A	033886 GASKET/DIAPHRAGM KIT	1
12	095383 VALVE, THROTTLE	1	B	051501 REPAIR KIT <i>030986</i>	1
13	055878 SCREW	1		004162 GASKET KIT	1
14	046496 SPRING, COIL	2		<i>091921</i> INCLUDES THE FOLLOWING	
15	052898 NEEDLE, IDLE	1		GASKET, CRANKCASE	1
16	037971 NEEDLE, HIGH SPEED	1		GASKET, CYLINDER BASE	1
17	094719 SPRING, THROTTLE RETURN	1		GASKET, INTAKE	1
18	042871 SHAFT, THROTTLE	1		GASKET, INTAKE	1
19	091307 CLIP	1		GASKET, MUFFLER	2
20	031619 SWIVEL	1		078844 GASKET, MUFFLER LID	1
				042749 COVER, MUFFLER	1

We reserve the right to change designs, specifications and equipment at any time without notice and without incurring any obligations.

LESCO, Inc., 20005 Lake Road, Rocky River, Ohio 44116-1545
Toll Free (800) 321-5325 • In the Cleveland Area (216) 333-9250

