




**POWER BLOWER
PARTS CATALOG
MODEL LHB-2100
S/N 005851 & UP**


**LESCO, INCORPORATED
20005 LAKE ROAD
ROCKY RIVER, OH 44116**

LHB-2100




KEY	PART NUMBER	QTY	DESCRIPTION	REMARKS
1	032660	1	CYLINDER	
2	080526	2	BOLT, H.S. 5X22	
3	-----	1	GASKET, CYLINDER BASE	USE KIT 065372
4	023943	1	RING, PISTON	
5	024528	1	PISTON	
6	029168	1	PIN, PISTON	
7	075288	1	BEARING, NEEDLE	
8	048344	2	CIRCLIP, PISTON PIN	
9	093607	2	SPACER, PISTON PIN	
10	027812	2	BEARING, BALL 6201	
11	060114	2	OILSEAL	
12	024977	1	CRANKCASE SET	INCLUDES ITEM 13
13	094428	2	PIN, DOWEL	
14	051455	1	CRANKSHAFT	INCLUDES ITEM 7
15	-----	1	GASKET, CRANKCASE	USE KIT 065372
16	069562	3	SCREW 5X28	
ENGINE REPOWER				
	084744	1	SHORT BLOCK	INCLUDES FACTORY ASSEMBLED CYLINDER, CRANKCASE, PISTON, CRANKSHAFT, BEARINGS & SEALS
	065372	1	GASKET KIT	INCLUDES ITEMS BELOW
		1	GASKET, CRANKCASE	
		1	GASKET, CYLINDER BASE	
		1	GASKET	
		1	GASKET	
		1	GASKET	
		2	GASKET, MUFFLER	
		1	COVER, MUFFLER	

LHB-2100



KEY	PART NUMBER	QTY	DESCRIPTION	REMARKS
1	042073	1	TUBE	
2	022650	1	CAP, SPARK PLUG	
3	024780	1	COIL, SPARK PLUG CAP	
4	058125	1	PLUG, SPARK BPM-7A	
5	097403	1	GROMMET	
6	061129	1	PAWL ASY, STARTER	INCLUDES ITEMS 7-10
7	038737	1	F-RING 4	
8	033448	1	CATCHER, PAWL	
9	088528	1	SPRING, RETURN	
10	056406	1	PAWL, STARTER	
11	059541	1	STARTER ASY	INCLUDES ITEMS 12-16, 19-21
12	059753	1	SCREW	
13	054575	1	WASHER	
14	053724	1	DREUM. STARTER	
15	039005	1	SPRING, REWIND	
16	093962	1	CASE, STARTER	
17	053827	1	SCREW 4X18	
18	071358	1	LABEL, LESCO	
19	038661	1	ROPE, STARTER	
20	038471	1	GUIDE, ROPE	
21	029106	1	GRIP, STARTER	
22A	023526	1	LEAD, GROUND	AFTER S/N 010709 & UP
23	067484	1	SWITCH, IGNITION	
24	067507	1	FLYWHEEL	
24A	023516	1	FLYWHEEL	AFTER S/N 010709 & UP
25	060341	1	HUB, FAN	
26	051383	2	SCREW 4X22	
27	061017	1	COIL, IGNITION	
27A	023514	1	COIL, IGNITION	AFTER S/N 010709 & UP
28	023531	1	LEAD	AFTER S/N 010709 & UP


LHB-2100



KEY	PART NUMBER	QTY	DESCRIPTION	REMARKS
1	051385	1	COVER, AIR CLEANER	
2	051386	1	FILTER, AIR	
3	086050	2	SCREW 5X64	
4	053031	1	PLATE, PREVENT	
5	051389	1	CASE, AIR CLEANER	2-34
6	059399	1	LABEL, CHOKE	
7	063388	1	CARBURETOR C1U-K26	
8	089887	1	GASKET, INTAKE	
9	020562	2	SCREW 5X22	
10	067130	1	GASKET, INTAKE	
11	034589	2	NUT 5	
12	043754	1	INSULATOR	
13	063446	1	NUT, WING 5	
14	044153	2	WASHER 5	
15	069886	2	BOLT, H.S. 5X55	
16	093731	1	MUFFLER ASY	INCLUDES ITEMS 17 - 24
17	028224	3	SCREW 4X10	
18	088643	1	LID, MUFFLER	
19	036675	1	GUIDE, EXHAUST	
20	078844	1	GASKET, MUFFLER LID	
21	071174	1	SCREEN, MUFFLER	
22	097667	1	MUFFLER	
23	016866	2	GASKET, MUFFLER	
24	023332	1	COVER, MUFFLER	

0-0938 27
 0-0131 23
 0-0101 20


LHB-2100



KEY	PART NUMBER	QTY	DESCRIPTION	REMARKS
1	033688	1	VENT ASY	
2	022289	1	COVER, VENT	
3	091344	1	CLIP, PIPE	
4	070395	1	PIPE 3X5X70	
5	093287	1	GROMMET, FUEL	
6	076965	1	CLIP	
7	075165	1	STRAINER, FUEL	
8	084229	1	PIPE, FUEL	
9	072951	2	SCREW 5X16	
10	076801	2	WASHER, SPRING 5	
11	060744	2	WASHER 5	
12	052545	1	TANK, FUEL CLEAR	
13	076047	1	CAP ASY, FUEL TANK	INCLUDES ITEM 14
14	097180	1	GASKET, FUEL TANK CAP	
15	074945	1	PIPE, FUEL	


REVISED 3/93

LHB-2100



KEY	PART NUMBER	QTY	DESCRIPTION	REMARKS
1	077423	1	SCREW 5X18	
2	084151	1	GRID, FAN CASE	
3	087101	6	SCREW 5X20	
4	027405	1	CASE, FAN (R-SIDE)	525
5	072085	1	FAN	
6	081481	1	LABEL, NOISE	
7	024927	1	CASE, FAN	7 90
8	045241	1	CONTROL, THROTTLE	
9	087401	1	ROD, THROTTLE	
10	078116	1	COVER, ENGINE SET	5.97
11	041564	1	LABEL, CAUTION	
12	053827	6	SCREW 4X18	
13	082449	1	BASE, ENGINE	
14	060420	1	LABEL, CAUTION	
15	071714	6	WASHER	
16	085548	5	SCREW 4X22	
17	023245	2	WASHER	
18	061613	1	NUT 8	141
19	043459	1	LABEL, MODEL	
20	092159	1	SPRING, GRID	
21	097229	1	SHAFT, GRID	
22	027652	6	SCREW 5X14	
23	037859	1	PIPE, BLOWER	
24	049760	1	NOZZLE, FAN HEAD	
25	084261	1	WRENCH, W/SCREW DRIVER	

LHB-2100



KEY	PART NUMBER	QTY	DESCRIPTION	REMARKS
	063388	1	CARBURETOR C1U-K26	INCLUDES THE FOLLOWING
1	067978	2	SCREW	
2	046630	1	COVER	
3	A B	1	DIAPHRAGM	
4	A B	1	GASKET, DIAPHRAGM	
5	A	1	PLUG, WELCH	
6	095383	1	VALVE, THROTTLE	
7	055878	1	SCREW	
8	046496	2	SPRING, COIL	
9	093298	1	NEEDLE, HIGH SPEED	
10	052890	1	NEEDLE, IDLE	
11	049954	1	SHAFT, THROTTLE	
12	094719	1	SPRING, THROTTLE RETURN	
13	034461	1	PIECE, FRICTION	
14	069083	1	SCREW, IDLE ADJUST	
15	053638	2	SCREW	
16	076192	1	RING	
17	074606	1	PUMP, PRIMER	
18	039961	1	COVER, PUMP	
19	A B	1	GASKET, FUEL PUMP	
20	A B	1	DIAPHRAGM, FUEL PUMP	
	A			
	061130			
	060785			
21	061766	1	STRAINER	
22		1	NOZZLE, CHECK VALVE	
23	091307	1	LEVER, THROTTLE	
24	A	1	SCREW	
	A			
25	A	1	CLIP	
26	A	1	VALVE, NEEDLE	
27	A	1	SPRING, COIL	
28	A	1	ARM, VALVE	
29	A	1	PIN	
30	097898	1	SCREW	
A	080611	1	REPAIR KIT	
B	099111	1	GASKET/DIAPHRAGM KIT	