


LHE - 2500 Edger

LHE - 2500

Parts List

ENGINE, LHE - 2500 EDGER




ENGINE, LHE - 2500 EDGER — PARTS LIST

Ref. LESCO		No.	Ref. LESCO	No.	Ref. LESCO	No.	
No.	No.	Description	No.	No.	Description	Description	
1	450972	Crankshaft	35	451083	Rubber	71 450948	Hose
2	450979	Piston Assembly (Includes 1 Ref. 3)	36	450985	Cylinder	72 450951	Rubber
3	450791	Ring, Piston	37	See Ref. 80	- Gasket, Muffler	73 450090	Hose
4	450793	Pin, Piston	38	450991	Muffler	74 450093	Rubber
5	450794	Clip, Piston Pin	39	450055	Arrester	75 450091	Valve, Reversing
6	450796	Bearing, Needle	40	450986	Baffle Plate, Outer	76 450949	Clip
7	450980	Crankcase Assembly (Includes 1 ea. Ref. 8, 9 and 2 ea. Ref. 10)	41	450075	Bolt, M5x48	77 450955	Connector
8	450009	Bearing, Ball	42	450989	Cowling, Cylinder	78 450997	Rubber
9	450010	Seal, Oil	43	450992	Baffle Plate	79 450956	Rubber
10	450012	Pin, Dowel	44	451080	Name Plate	80 450998	Gasket Kit (Includes 1 ea. Ref. 37, 45 and 52.)
11	450974	Crankcase Assembly (Includes 1 ea. Ref. 8 and 9)	45	See Ref. 80	- Gasket, Insulator	81 450901	Wire Holder
12	450062	Bolt, M5x25	46	450993	Bolt, M5x56	82 451099	Gasket
13	450815	Pulley Assembly, Starter (Includes 1 Ref. 14)	47	450995	Insulator	83	<i>450902 muffler screen</i>
14	450823	Ratchet	48	450941	Adjuster		
15	450816	Recoil Assembly (Includes 1 ea. Ref. 16 and 17)	49	450053	Bolt, M5x12		
16	450827	Rope, Starter	50	027090	Nut		
17	450833	Knob, Starter	51	029349	Washer		
18	450836	Name Plate	52	See Ref. 80	- Gasket		
19	450975	Coil Assembly, Ignition	53	450938	Carburetor Assembly (Includes 1 ea. Ref. 54, 55, 56, 57, 58 and 59)		
20	050889	Bolt, M4x20	54	450943	Valve, Float		
21	450044	Spring	55	450068	Gasket		
22	450045	Cap, Plug	56	450069	Diaphragm, Metering		
23	058125	Spark Plug	57	450070	Diaphragm, Pump		
24	450977	Flywheel, Magneto	58	450945	Gasket		
25	450981	Clutch Assembly	59	451031	Rubber		
26	450047	Bolt, M5x20	60	450944	Case, Air Silencer		
27	450983	Housing, Blower	61	450990	Nut		
28	450022	Bolt, M5x16	62	450064	Element "B", Air Filter		
29	451091	Drum, Clutch	63	450076	Element "A", Air Filter		
30	450982	Snap Ring, S-12	64	450994	Cap, Case		
31	450984	Collar	65	450922	Wire Complete, Throttle		
32	450014	Bolt, M5x30	66	450996	Tank, Fuel		
33	450871	Nut	67	450084	Cap Assembly, Fuel Tank (Includes 1 Ref. 68)		
34	451086	Plate	68	450085	Gasket		
			69	450081	Filter, Fuel		
			70	450082	Clip		

Mount Block
 PT# 451196

SHAFT, LHE - 2500 EDGER



Drive Shaft Patents:
U.S.A. 4126928-4226021-4335585
U.K. 1597434
France Brevete S.G.D.G.
Canada Patented/Brevete 1980

SHAFT, LHE - 2500 EDGER — PARTS LIST

Ref. LESCO			No.	Ref. LESCO			No.
No.	No.	Description	Used	No.	No.	Description	Used
1	060512	Housing, Drive Shaft.....	1	31	060535	Debris Flap	1
2	060513	Drive Shaft, Flexible, 1/4 x 5/8	1	32	060536	Mach. Screw, # 10-24 x 5/8	
3	060514	Handle, Tear Drop (Includes 1 ea. Ref. 4 and 2 ea. Ref. 5 and 6)	1			Phil. Hd.	2
4	060515	Clamp, Tear Drop Handle.....	1	33	060537	Flat Washer, #10	2
5	060517	Cap Screw, 1/4-20 x 1-3/4 Button Hd.	2	34	002540	Safety Goggles	1
6	060516	Hex Nut, 1/4-20 Nylock	4	35	450119	Wrench, Spanner Box 13x19.....	1
7	060518	Grip	1	36	060541	Operator's Manual	1
8	451020	Lever Assembly Throttle	1				
9	451018	Wire, Throttle	1				
10	451134	Harness, Wire	1				
11	451135	Harness, Wire	1				
12	451199	Connector	2				
13	451200	Sleeve	2				
14	060520	Gear Head (Includes 1 ea. Ref. 15, 16 and 18 and 2 ea. Ref. 17)	1				
15	060538	Grease Plug	1				
16	060539	Locating Screw, Flat washer and Lock Washer (Kit includes 2 ea. Ref. 17)	1				
17	060539	Clamping Screw (Kit includes 1 ea. Ref. 16)	2				
18	060521	Cup Washer	1				
19	050535	Blade, 8" Strait Cut	1				
20	060523	Blade Nut, 10 mm, L.H.	1				
21	060522	Arbor Washer	1				
22	060524	Side Plate	1				
23	060527	Blade Guard	1				
24	060525	Mach. Screw, #8-32 x 1/2.....	4				
25	060529	Bottom, Blade Guard	1				
26	060531	Adjustment Knob	1				
27	060530	Cap Screw, 1/4-20 x 1 Soc. Hd.	1				
28	060532	Wheel	1				
29	060533	Bolt, Shoulder	1				
30	060534	Washer	1				



LIMITED WARRANTY FOR HAND HELD POWER EQUIPMENT

LESCO, Inc.'s limited warranty promises to you, the original retail purchaser, that the unit of LESCO hand held power equipment you purchased (the "Product") will be free from defects in material and workmanship for a period of one (1) year from the date of retail purchase (the "Warranty period"). LESCO agrees to repair or replace, at LESCO's option, any defective Product free of charge during the Warranty Period. Upon completion of your purchase, the Serial Number of the Product will be registered with LESCO, Inc. This will initiate and validate your limited warranty. Please keep your purchase receipt and present it to an authorized LESCO servicing facility for warranty service. Parts replaced or repaired under this limited warranty are warranted only to the end of the Warranty Period. All defective parts replaced under this Limited Warranty become the property of LESCO, Inc. For warranty service, you must, at your own expense, deliver the Product to, and pick it up from, an authorized LESCO servicing facility. To locate your nearest authorized LESCO servicing facility, call LESCO, Inc. toll free at 1-800-321-5325.

This limited warranty is given by LESCO to the original retail purchaser only, and is not transferable to subsequent owners. This warranty does not cover damage to the Product resulting from any cause other than defects in material or workmanship. This warranty specifically does not cover damage caused by:

1. Lack of lubrication or engine failure due to the use of oils other than LESCO-approved oils.
2. The use of gasohol containing methyl (wood) alcohol or gasoline containing less than 89 octane. Only use gasoline which contains 89 octane or higher or gasohol which contains a maximum 10% ethyl (grain) alcohol or 15% MTBE (methyl tertiary-butyl ether). (The prescribed mixing ratio of gasoline to oil is listed on the LESCO oil label.)
3. Defects, malfunctions or failures resulting from abuse, misuse, modifications, alterations, improper servicing or maintenance, improper storage, use of unauthorized attachments, including, without limitation, failure to provide or perform required maintenance services as described in the Operator's Manual.
4. Tampering with engine speed governors or running engines above specified and recommended engine speeds.
5. Dirt, salt water corrosion, rust, varnish and moisture.
6. Operation of the Product with improperly serviced, damaged or removed air filter.
7. Failure to follow the set-up, pre-delivery service and adjustments outlined in the Operator's Manual.
8. Parts which are not warranted. (This limited warranty does not cover parts which are normal wear or maintenance items, including, without limitation, spark plugs, filters, lubricants, engine tune-up parts, spark arrestor screen, cutting line and starter cords.)
9. Engine damage caused by the use of ether or any starting fluids.
10. Damage caused by the pressure of steam cleaning the Product.
11. Repairs or alterations made to the Product by an unauthorized party.

THIS LIMITED WARRANTY IS IN PLACE OF ALL OTHER EXPRESS AND IMPLIED WARRANTIES. ANY IMPLIED WARRANTY, SUCH AS FITNESS FOR A PARTICULAR PURPOSE OR MERCHANTABILITY, IS EXCLUDED. REPAIR OR REPLACEMENT UNDER THIS LIMITED WARRANTY IS EXPRESSLY AGREED TO BE THE EXCLUSIVE REMEDY. LESCO, INC. WILL NOT BE LIABLE FOR ANY SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES.

SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER LEGAL RIGHTS WHICH VARY FROM STATE TO STATE.

HOW TO ORDER PARTS

Contact your LESCO Salesperson, OR phone us (use the numbers below), OR write us (use the address below). We will need the following information:

1. Your account number if available.
2. Your name and address and the address where you want the parts to be shipped.
3. The Model/Serial No. of the equipment.
4. The LESCO Part No. and the quantity desired. (Please do not use reference numbers.)

NOTE: Inspect all shipments on receipt for damage or missing parts. File a claim with the carrier before accepting a damaged shipment.

We reserve the right to change designs, specifications and equipment at any time without notice and without incurring any obligations.

LESCO, Inc., 20005 Lake Road, Rocky River, Ohio 44116-1545
Toll Free (800) 321-5325 • In the Cleveland Area (216) 333-9250



20005 LAC