LESCO® 36" DROP SPREADER



	LESCO 36" Drop Spreader #092474
Capacity	120 lb. [approx.]
Spreading Width	36"
Wheels	13" Pneumatic tires Heat Treated
Rotor	Three welded steel rods spaced uniformly around rotor tube
Rotor Bearings	Oil impregnated, sintered bronze alloy, sleeve type
Hopper Bottom & Rate Control	Stainless Steel, bottom snaps off for easy cleaning
Hopper Opening	1" long triangular openings spaced 1-1/8" apart
Shutoff	Positive-action handle lever opens and closes drop plat.
Handles	Rugged 1" I.D., 16-gauge tubing
Weight	61 lb. [approx.]
Warranty*	1 Year

^{*}Consult Owners Manual for full warranty details.

m
•
യ
.=
$\overline{}$
·
ഗ
Č
٠,
യ
$\overline{\Box}$
ب
\circ
$\overline{}$
~
_
$\overline{\mathbf{x}}$
w
\Box
=
u
-
~

Hopper Cover - 014525	Minimizes fertilizer dust getting out and moisture getting in
Pneumatic Wheel - 2813896	Wheel assembly for 36" Drop Spreader
Jigglers - 28368759	Vibrates against rotors to provide agitation for materials being applied (Two (2) Required)
Tow-Hitch Assembly - 28368713	Convert walk behind spreader to a pull behind with this kit
Calibration Tray - 28368584	Properly calibrate your spreader with this Calibration Tray
Measuring Wheel - 007876	Obtain precise measurement of turf areas; Helps aid in proper calibration of spreader
Seed	From Professional to Premium Grades, superior seed with proven performance
Starter Fertilizer	Specially formulated for successful seed germination and root development
Seed Starter Mulch - 056000	Keeps the seed in place and helps retain moisture

