


Model LCS 5100 Chain Saw Parts List




LESCO Model LCS 5100, LESCO No. 055520

Serial No. _____

Date Purchased _____

LESCO™


ENGINE — ILLUSTRATION



ENGINE — PARTS LIST


Ref. No.	LESCO No.	Description	No. Used	Ref. No.	LESCO No.	Description	No. Used
1	450758	Cylinder and Piston	1	41	450792	Hose	1
2	450770	Gasket, Cylinder	1	42	450807	Hose, Oil	1
3	450759	Piston Ring	2	43	450668	Strainer, Oil	1
4	450771	Piston Pin	1	44	450814	Pump, Oil	1
5	450780	Circlip	2	45	450681	Washer	2
6	450760	Piston	1	46	450670	Spring	1
7	450762	Crankshaft	1	47	450795	Pump Piston	1
8	450772	Bearing, Needle	1	48	450624	Circlip	1
9	450781	Woodruff Key	1	49	450810	Washer	1
10	450873	Crankcase Complete	1	50	450604	Activator	1
11	450761	Gasket, Crankcase	1	51	450799	Screw, Flat Hd.	7
12	450616	Washer	4	52	450797	Spring, Cup	1
13	450661	Screw, Tension	1	53	450812	Screw	1
14	450677	Bolt, Chain Tension	1	54	450884	Cover, Pre-filter	1
15	450783	Washer	1	55	450127	Pre-filter	1
16	450774	Bearing, Ball	1	56	450798	Connection, Rubber Metal	4
17	450613	Bearing, Ball	1	57	450878	Cover, Protection	2
18	450784	Seal, Oil	1	58	450811	Plate, Battle Protection	1
19	450775	Seal, Oil	1	59	450934	Cover	1
21	450883	Console	1	60	450799	Screw, Flat Hd.	4
22	450765	Plug	1	61	450702	Screw	3
23	450776	Screw	2	62	450654	Screw	1
24	450785	Throttle Linkage	1	63	450800	Spacer	1
25	450766	Screw, Flat Hd.	4	64	450672	Spring, Torsion	1
26	450777	Circlip	4	65	450675	Bucking Spike	1
27	450786	Rubber	2	66	450801	Scabbard	1
28	450632	Spark Plug	1	67	450817	Rivet, Tubular	1
29	450778	Screw, Flat Hd.	1	68	450802	Screw	2
30	450787	Plate	1	69	450650	O-Ring	1
31	450651	O-Ring	1	70	450925	Guide Bar, 20"	1
32	450779	Muffler	1	71	450927	Chain, 20" Loop	1
33	450789	Screw, Flat Hd.	4				
34	450788	Gasket, Exhaust	1				
35	450769	Cap, Tank = 450769	1				
36	450790	Gasket	1				
37	450805	Pin	1				
38	450935	Plate, Stop	1				
39	450660	Valve, Check	1				
40	450933	Cover, Brake	1				

HANDLE BAR / HOUSING




Ref. No.	LESCO No.	Description	No. Used	Ref. No.	LESCO No.	Description	No. Used
1	450885	Housing, Handle	1	24	450929	Cover, Top	1
2	450818	Lever	1	25	450826	Cord, Sealing	9.25 in.
3	450832	Pin, Stop	1	26	450849	Nipple	1
4	450819	Spring, Pressure	1	27	450812	Screw	5
5	450842	Screw	2	28	450837	Plug	1
6	450843	Throttle Control	1	29	450906	Cover, Air Filter	1
7	450718	Spring, Throttle Control	1	30	450657	Washer	1
8	450723	Throttle Linkage	1	31	450850	Lever, Choke	1
9	450820	Lever, Safety	1	32	450851	Decal	1
10	450732	Lever, Retainer	1	33	450858	Safety Catch 1	1
11	450821	Spring	1	34	450855	Safety Catch 2	1
12	450733	Fuel Pick-up	2	35	450859	Safety Catch 3	1
13	450822	Sleeve	1	36	450852	Safety Catch 4	1
14	450834	Hose, Fuel	1	37	450840	Screw, Flat Hd.	1
15	450715	Hose Guide	2	38	450841	Washer	1
16	450769	Cap, Tank	1	39	450905	Grip Cup, Left	1
17	450845	Hose, Vent	1	40	450786	Spacer, Rubber	2
18	450835	Filter	1	41	450853	Insulating Foil	1
20	450824	Handle Bar	1	43	450736	Hose Loop	2
21	450702	Screw	4	45	450839	Frame	1
22	450848	Nut	1	47	450838	Fuel Pick-up	1
23	450825	Connection, Rubber Metal	1				

CHAIN BRAKE / CLUTCH




Ref. No.	LESCO No.	Description	No. Used	Ref. No.	LESCO No.	Description	No. Used
1	450720	Hand Protector	1	11	450691	Spring, Pressure	1
2	450653	Washer, Spring	1	12	450689	Brake Band	1
3	450729	Bolt	1	13	450605	Circlip	1
4	450688	Nut, Lock	1	14	450846	Washer	1
5	450687	Bolt	1	15	450861	Clutch Drum	1
6	450806	Shoe, Guide	2	16	450638	Bearing, Needle	1
7	450928	Guard, Chain (Side Cover)	1	17	450868	Spring, Clutch	1
8	450690	Adjuster	1	18	450866	Clutch Assembly (Incl. 1 ea. Ref. 17) ...	1
9	450655	Spring, Pressure	1	19	450863	Sprocket, Rim	1
10	450666	Lock, Release	1	20	450755	Hex Nut	2

STARTER




Ref. No.	LESCO No.	Description	No. Used	Ref. No.	LESCO No.	Description	No. Used
1	450930	Starter Assembly	1	7	450742	Pulley, Starter	1
2	450931	Housing, Starter	1	8	450743	Pawl, Starter	1
3	450812	Screw	4	9	450740	Pawl Guide	1
4	450741	Grip, Starter	1	10	450744	Pin	1
5	450739	Rope, Starter	1	11	450932	Decal, "LESCO"	1
6	450656	Spring, Starter	1				

CARBURETOR



Ref. No.	LESCO No.	Description	No. Used	Ref. No.	LESCO No.	Description	No. Used
1	450745	Gasket, Manifold	1	9	450776	Screw	1
2	450870	Gasket, Carburetor	1	10	450881	Screw, Stud	2
3	450879	Manifold	1	11	450865	Washer, Spring	2
4	450766	Screw, Flat Hd.	2	12	450877	Filter, Air	1
5	450698	Circlip	2	13	450867	O-Ring	1
6	450880	Guide Piece, Adjustment Screws	1	14	450882	Screw	2
7	450764	Carburetor	1	15	450696	Profile	1
8	450875	Plate	1				

ELECTRICAL



Ref. No.	LESCO No.	Description	No. Used	Ref. No.	LESCO No.	Description	No. Used
1	450627	Cap, Spark Plug	1	9	450773	Washer, Spring	2
2	450610	Spring, Contact	1	10	450908	Screw, Flat Hd.	2
3	450886	Hose	4 in.	11	450913	Grommet	1
4	450631	Grommet	1	12	450907	Fan Wheel	1
5	450887	Cable, Short Circuit	1	13	450642	Washer, Spring	1
6	450909	Grommet	1	14	450646	Nut	1
7	450628	Switch, Short Circuit	1	15	450914	Cover, Air	1
8	450888	Coil, Ignition	1				



LIMITED WARRANTY FOR HAND HELD POWER EQUIPMENT

LESCO, Inc.'s limited warranty promises to you, the original retail purchaser, that the unit of LESCO hand held power equipment you purchased (the "Product") will be free from defects in material and workmanship for a period of one (1) year from the date of retail purchase (the "Warranty period")

LESCO agrees to repair or replace, at LESCO's option, any defective Product free of charge during the Warranty Period. Upon completion of your purchase, the Serial Number of the Product will be registered with LESCO, Inc. This will initiate and validate your limited warranty. Please keep your purchase receipt and present it to an authorized LESCO servicing facility for warranty service. Parts replaced or repaired under this limited warranty are warranted only to the end of the Warranty Period. All defective parts replaced under this Limited Warranty become the property of LESCO, Inc. For warranty service, you must, at your own expense, deliver the Product to, and pick it up from, an authorized LESCO servicing facility. To locate your nearest authorized LESCO servicing facility, call LESCO, Inc. toll free at 1-800-321-5325.

This limited warranty is given by LESCO to the original retail purchaser only, and is not transferable to subsequent owners. This warranty does not cover damage to the Product resulting from any cause other than defects in material or workmanship. This warranty specifically does not cover damage caused by:

1. Lack of lubrication or engine failure due to the use of oils other than LESCO-approved oils
2. The use of gasohol containing methyl (wood) alcohol or gasoline containing less than 89 octane. Only use gasoline which contains 89 octane or higher or gasohol which contains a maximum 10% ethyl (grain) alcohol or 15% MTBE (methyl tertiary-butyl ether). (The prescribed mixing ratio of gasoline to oil is listed on the LESCO oil label.)
3. Defects, malfunctions or failures resulting from abuse, misuse, modifications, alterations, improper servicing or maintenance, improper storage, use of unauthorized attachments, including, without limitation, failure to provide or perform required maintenance services as described in the Operator's Manual.
4. Tampering with engine speed governors or running engines above specified and recommended engine speeds.
5. Dirt, salt water corrosion, rust, varnish and moisture.
6. Operation of the Product with improperly serviced, damaged or removed air filter.
7. Failure to follow the set-up, pre-delivery service and adjustments outlined in the Operator's Manual.
8. Parts which are not warranted. (This limited warranty does not cover parts which are normal wear or maintenance items, including & without limitation, spark plugs, filters, lubricants, engine tune-up parts, spark arrestor screen, cutting line and starter cords.)
9. Engine damage caused by the use of ether or any starting fluids.
10. Damage caused by the pressure of steam cleaning the Product.
11. Repairs or alterations made to the Product by an unauthorized party.

THIS LIMITED WARRANTY IS IN PLACE OF ALL OTHER EXPRESS AND IMPLIED WARRANTIES. ANY IMPLIED WARRANTY, SUCH AS FITNESS FOR A PARTICULAR PURPOSE OR MERCHANTABILITY, IS EXCLUDED. REPAIR OR REPLACEMENT UNDER THIS LIMITED WARRANTY IS EXPRESSLY AGREED TO BE THE EXCLUSIVE REMEDY. LESCO, INC. WILL NOT BE LIABLE FOR ANY SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES.

SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER LEGAL RIGHTS WHICH VARY FROM STATE TO STATE.

HOW TO ORDER PARTS

Contact your LESCO Salesperson, OR phone us (use the numbers below), OR write us (use the address below). We will need the following information:

1. Your account number if available.
2. Your name and address and the address where you want the parts to be shipped.
3. The Model/Serial No. of the equipment.
4. The LESCO Part No. and the quantity desired. (Please do not use reference numbers.)

NOTE: Inspect all shipments on receipt for damage or missing parts. File a claim with the carrier before accepting a damaged shipment.

We reserve the right to change designs, specifications and equipment at any time without notice and without incurring any obligations.

LESCO, Inc., 20005 Lake Road, Rocky River, Ohio 44116-1545
Toll Free (800) 321-5325 • In the Cleveland Area (216) 333-9250

